


Besam Curved Sliding Door System CMD

Installation and Service Manual - Original instructions



ILL-00224

© All rights in and to this material are the sole property of ASSA ABLOY Entrance Systems AB. Copying, scanning, alterations or modifications are expressly forbidden without the prior written consent of the applicable company within ASSA ABLOY Entrance Systems AB. Rights reserved for changes without prior notice.

Backtrack information: folder: Library, version: a330, date: 2012-02-14, time: 12:36:26, state: Working

CONTENTS

1	Revision	4
2	Important information	5
3	Design and function description	7
4	Technical specification	8
5	Models	10
6	Identification	11
7	Mechanical installation	15
8	Electrical connections	19
9	Start-up	30
10	Signage	33
11	Programme selectors and functions	34
12	Troubleshooting function	36
13	Maintenance/Service	42
14	Accessories	46

1 Revision

Page	Revision 2.0 → 3.0
5	Module text updates
34	Illustration of programme selector updated
34	Connection illustration updated
24	Connection illustration updated
33	Product label updated
19	Illustration updated
35	Illustration of programme selector updated
35	Illustration of programme selector updated
36	New table rows added
46	Text update

2 Important information

HAZARD WARNING!



Failure to observe the information in this manual may result in personal injury or damage to equipment.

Save these instructions for future reference.

2.1 Intended use

The Besam CMD is an automatic sliding door operator developed to facilitate entrances to buildings and within buildings through sliding doors.

The Besam CMD is designed to be surface-mounted to the wall or a beam. It is easy to install for both new construction and retrofit application, and it can be adapted to a wide range of door requirements. It is to be installed indoors where it is suitable for almost all types of external and internal sliding doors.

A Besam CMD operator can be combined with the full range of Besam safety units, such as presence and motion sensors.

The door operator is designed to offer continuous use, a high degree of safety and maximum lifetime.

For use see User manual 1006492.

2.2 Safety precautions

When open the box check that door leaves have not shifted during transport. Always use tools provided for lifting.

Do not climb on door parts.

Do not let children play with the door or the fixed controls.

Keep remote controls away from children.

Be sure to complete the site acceptance test before taking the door into operation, see PRA-0005.

To avoid bodily injury, material damage and malfunction of the product, the instructions contained in this manual must be strictly observed during installation, adjustment, repairs and service etc. Training is needed to carry out these tasks safely. Only Besam-trained technicians should be allowed to carry out these operations.

2.3 Electronic equipment reception interference

The equipment complies with the European EMC directive (US market FCC Part 15), provided installed according to Installation and Service manual.

The equipment may generate and use radio frequency energy and if not installed and used properly, it may cause interference to radio, television reception or other radio frequency type systems.

If other equipment does not fully comply with immunity requirements interference may occur. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient the receiving antenna.
- Relocate the receiver with respect to the equipment.
- Move the receiver away from the equipment.
- Plug the receiver into a different outlet so that equipment and receiver are on different branch circuits.
- Check that protective earth (PE) is connected.

If necessary, the user should consult the dealer or an experienced electronic technician for additional suggestions.

2.4 Environmental requirements

Please act according to your local regulations and dispose of your unused product(s) and packaging properly. The correct disposal will help prevent potential negative consequences for the environment and human health.

Besam products are equipped with electronics and may also be equipped with batteries containing materials which are hazardous to the environment. Remove this material from the operator before it is scrapped and make sure that it is disposed of properly as was done with the packaging.

This manual contains the necessary details and instructions for the installation, maintenance and service of the Sliding Door Operator Besam CMD.

3 Design and function description

Design

The sliding door CMD works electromechanically. The motor, control unit, transmission – and optional emergency unit and electromechanical locking device – are all assembled in a support beam with an integrated cover. The motor and gear box transmit movement to the door leaves by means of a tooth belt. The door leaf is fitted to a door adapter/carriage wheel fitting and hangs on a sliding track. Movement of the bottom of the door leaf is controlled by the floor guides.

Function

Opening

When an OPENING IMPULSE is received by the control unit the motor starts and transmits movement to the door leaves, which move to the open position.

Closing

The closing starts when no OPENING IMPULSE is received and the HOLD OPEN TIME has run out.

Safety functions integrated in the operator

To permit safe passage between closing doors, the doors immediately reverse if an obstruction is detected, then resume their interrupted movement at low speed to check whether the obstruction has disappeared or not. If an obstruction is detected between opening doors and surrounding walls or interior fittings, the doors immediately stop and then close after a time delay.

Microprocessor for precise control

The microprocessor has a routine for self-monitoring, which detects any interference or faulty signals in door operation. If an input signal does not correspond to the preprogramming, the microprocessor automatically takes necessary actions to ensure safe door operation.

Emergency escape

The Besam CMD can be combined with an emergency unit that automatically opens or closes¹ the doors in the event of a power failure and can also be interfaced with the fire alarm or smoke detector.

Doors used for emergency escape in buildings such as hospitals and homes for elderly people may not be locked or put in programme selection OFF.


¹ Electrical emergency unit only

4 Technical specification


Manufacturer:	ASSA ABLOY Entrance Systems AB
Address:	Lodjurgatan 10, SE-261 22 Landskrona, Sweden
Type:	CMD
Mains power supply:	120 V AC -10% to 240 V AC +10% 50/60 Hz fuse 10 AT Note! Switch with clearly marked off-position, having a contact separation of at least 3 mm in all poles, must be incorporated in the fixed wiring, be installed at a minimum height of 1.5 m and not be accessible for the public.
Power consumption:	Max. 250 W
Auxiliary voltage:	24 V DC, 640 mA
Control unit fuse:	6,3 AT
Recommended max. door weight:	100 kg/leaf
Minimum radius:	900 mm
Opening and closing speed:	Variable up to approx. 1.4 m/s
Hold open time:	0-60 s
Ambient temperature:	-20°C to +50°C
Relative humidity (non-condensing):	Max. 85%
Approvals:	Third party approvals from established certification organizations valid for safety in use and escape route safety. For details see Declaration of Conformity.
For indoor use only	

Classification to DIN 18650-1							
Digit 1	Digit 2	Digit 3	Digit 4	Digit 5	Digit 6	Digit 7	Digit 8
2	3	2	0	1,2,3	1,2	1,2,4	4
Type of drive, digit 1.			2	sliding door drive			
Drive durability, digit 2.			3	1 000 000 test cycles, at 4 000 cycles/day			
Type of door leaf, digit 3.			2	sliding door			
Suitability for use as a fire protection door, digit 4.			0	not suitable for use as a fire protection door			
Drive safety devices, digit 5.			1	force limitation			
			2	connection for external safety systems			
			3	low energy			
Special requirements for drives/functions/fittings, digit 6.			1	in escape routes with a break-out system			
			2	in escape routes without a break-out system			
Safety at door leaf or leaves, digit 7			1	with sufficiently dimensioned safety distances			
			2	with protection to prevent fingers being crushed, shorn off or drawn in			
			4	with presence sensor			
Ambient temperature, digit 8			4	temperature range as specified by the manufacturer			

5 Models




6 Identification



ILL-00207

No.	Description
1	Operator cover
2	Operator support beam (incl. sliding track)
3	Screens left and right
4	Doors left and right (incl. floor guide)
5	Presence sensor


6.1 Operator




No.	Description
1	Cover
2	Tension wheel
3	Tooth belt
4	Control unit
5	Drive unit
6	Drive wheel
7	Drive arm
8	Carriage wheel fitting
9	Operator support beam (incl. sliding track)
10	Bracket for drive module
11	Mains power connection block
12	Door stop
13	Programme selector board
14	Electromechanical locking device, option
15	Mechanical Emergency Unit (MEU), option
16	Electrical Emergency Unit (EEU), option

6.2 Function

6.2.1 Integrated safety detection




6.2.2 Safety detection with presence sensor




6.2.3 Emergency escape

- The operator can be fitted with different emergency escape units to ensure a safe evacuation of the building: Mechanical emergency unit (MEU) or Electrical emergency unit (EEU). The units can also be interfaced with the fire alarm or smoke detector.

①




②



ILL-00115

③




The door is opened by means of an emergency escape unit in the event of a power failure. The door remains in this position until the power is restored. The operator will then resume the function set by the programme selector. The emergency unit is monitored by the operator control unit. A monitoring error means that the door opens and remains open until the error is cleared.


For further information see “General accessories” on page 46.

The electrical emergency function can also be used to close the door in the event of power failure. The fire authorities make this a requirement to stop fire or smoke from spreading throughout the building.

7 Mechanical installation


7.1 Floor surface




② 

FLOOR			
Point	Value	Highest point	Deviation/Shim (max. 6 mm)
1			
2			
3			
4			
5			
6			

Max. (mm)
 ↑ + 3
 ↓ - 3




④ 

FIXING RAILS			
Point	Value		Deviation/Shim (max. 1 mm)
1			
2			
3			
4			
5			
6			


Max. (mm)
 ↑ + 0,5
 ↓ - 0,5

ILL-00154


7.2 Fixing rails



7.3 Outer walls and Support beam



7.4 Hanging the door leaves



8 Electrical connections

Note! During any work with the electrical connections the

- **mains power** and the
- **electrical emergency unit must be disconnected.**


Installation

- a Open the cover.
- b Install extension unit EXU-4 or EXU-3 if required, see page 29.
- c Install and connect the mains cables, see below.
- d Carry out Start-up, see page 30.



Mains connection

- a Unscrew the fastening screw and remove the protective lid.
- b Connect the incoming mains power through the strain relief to the connection block as shown in the illustration below.
- c Connect the protective earth to the cover.
- d Put the protective lid back in place.

①




②




8.1 Control unit

The control unit is equipped with


8.1.1 Contacts for connection of standard units










8.1.2 Terminal block for connection of accessories




8.1.3 Function selector, FS, used to select special operating functions




Function selector (FS)	OFF	ON
1. Motor direction of rotation [Always to be set to ON]		CW
2. Lock type (locked with/without power)	With  ILL-00200	Without  ILL-00201
3. Lock release [To be set to ON if electric lock is installed]	No	Yes
4. Presence detection type (normally OPEN/closed) [Applies in common for the terminals 11, 12 and 13 on the control unit CUF and terminal 4 on the EXU-4] 	NO  ILL-00203	NC  ILL-00204
5. Emergency unit type [If no emergency unit is installed the parameter should be set to OFF]	 ILL-00205	 ILL-00206
6. Emergency unit monitoring [To be set in accordance with local authority requirements]	No	Yes
7. Sensor monitoring [To be set in accordance with local authority requirements]	No	Yes
8. Hold force on closed door (0 N / 45 N) [Setting ON always recommended]	No	Yes

Note! Press the LEARN BUTTON briefly after any FS adjustment to ensure proper configuration.



8.1.4 Potentiometers and LEARN BUTTON




The potentiometers are factory set to approx. 50% of the adjustment range.


Note! The speed applies to a single leaf.

Note! Press the LEARN BUTTON briefly after any potentiometer adjustment, to use the new configuration. The speed applies to single sliding operator.

8.1.5 Connection of programme selectors



8.1.6 Connection of activation units




*) Can be monitored

***) Only to be connected if inner impulse monitoring is required, FS-7 = ON


ILL-02244

- ① Inner impulse
- ② Outer impulse
- ③ Presence impulse, NO
- ④ Presence impulse, NC
- ⑤ Stop impulse
- ⑥ Key impulse / (Emergency open impulse, EEU required)

Note! If necessary, adjust the sensor detection fields to meet the specific application and regulation requirements



*) Can be monitored
 **) Only to be connected if inner impulse monitoring is required, FS-7 = ON




ILL-01548


- ① Inner impulse
- ② Outer impulse
- ③ Presence impulse, NO
- ④ Presence impulse, NC
- ⑤ Stop impulse
- ⑥ Key impulse / (Emergency open impulse, EEU required)

8.1.7 Side presence sensors

Sensor # 1 Sensor # 2



EXU-4 / CUF



ILL-02245

*) Can be monitored


***) If side presence impulse monitoring is **not** selected (=off), the sensor monitoring input should be connected to EXU-4: 1 (0V DC)

8.2 Extension units

When functions beyond those implemented on the main control unit are required, two extension units are available, EXU-4 and EXU-3. These units are to be applied on top of the control unit (if not factory installed).

Note! When installing or replacing an extension unit the LEARN BUTTON LB **must** be pushed for a minimum of 2 seconds.


8.2.1 Fitting the extension units EXU-4 or EXU-3 to the control unit CUF



- a Fastening screws (2 pcs)
- b Tagstrip (long pins to be fitted into the EXU)
- c Extension unit, EXU-4 or EXU-3
- d Label (EXU-4 or EXU-3)
- e Lid
- f Screw for fixing the lid

8.2.2 Extension unit, EXU-4

Following functions can be obtained with this unit:




¹⁾ Connects the battery in absence of main power

²⁾ Total load on all 24 V DC, max. 640 mA


8.2.3 Extension unit, EXU-3

This extension unit has the functions **electrical emergency unit** or **convenience battery**. The battery cable is to be connected to the EXU-3.




9 Start-up

After installing the automatic door, the Start-up and adjustment must be carried out in the following order (see also Electrical connections on page 19).







ILL-02246





If necessary, adjust the door speeds to meet the specific application and regulation requirements.


Note! The LOW SPEED is self adjusting to optimal operation if the LOW SPEED parameter is set to **max**. Depending on authority or installation requirements the LOW SPEED can be further reduced.



Note! Press the LEARN BUTTON briefly after any potentiometer adjustment, to use the new configuration.

Note! Check that the installation complies with valid regulations and requirements from the authorities.

10 Signage



Mandatory indicates that the signage is required by European directives and equivalent national legislation outside the European Union.

Ⓐ	Product label: Mandatory
Ⓑ	Besam door sticker: Mandatory, if applicable, to highlight the presence of the glass (applied to both sides of the door).
Ⓒ	Supervision of child: Mandatory, if applicable (applied to both sides of the door). To be placed on entrances where the risk analysis shows use by children, elderly and disabled.
Ⓓ	Operator designed for disabled people: Recommended, if applicable (applied to both sides of the door)
Ⓔ	Activation by disabled people: Recommended, if applicable
Ⓕ	No entry, identifying one-way traffic: Mandatory in GB and US, if applicable
Ⓖ	Automatic door: Only mandatory in GB
Ⓗ	Keep clear: Only mandatory in GB

11 Programme selectors and functions


11.1 Operation

The functions of the door are set with key programme selectors. The key must always be removed on emergency escape doors after changing settings.


- PSO-5R, can be fully remote-controlled by PS-5M.
- PSO-5T, can be remote-controlled, day/night by PS-2, used for MEU.
- PSMB-5, mounting box, flush or surface mounted on the side screen or on the wall close to the door.
- PS-5M, flush or surface mounted, for central control of an optional number of operators. In setting AUTO every connected operator are individually controlled by its own programme selector.
- PSK-6U, surface mounted on the side screen or on the wall close to the door.

Mounted in the operator


PSO-5R




PSO-5T



Flush mounted

PSMB-5
PS-5M

Surface mounted

PSMB-5
PS-5M


PSK-6U



11.2 Programme selector functions

Note! The key must always be removed on emergency escape doors after changing settings.

Note! In OFF: The door can be manually pulled open if no mechanical/electromechanical lock is fitted



<p>"Reset"</p>	<p>The operator makes a system test of the battery (if selected), electromechanical lock, watch dog relay and closed position. The operator is after closing, RESET and ready for normal operation.</p> <p>Note! The RESET is not available on the PS-5M.</p>
-----------------------	--

Note! If monitored emergency unit is a demand, a test of the emergency unit is performed when the programme selector is turned from OFF or OPEN to any other position.

12 Troubleshooting function

Before starting the troubleshooting, check that the programme selector setting is correct and then RESET the operator. Start the troubleshooting by checking the mechanical and electrical parts of the operator in the following order.

The control unit, emergency unit and electromechanical lock are fixed with brackets in the support beam. To replace, the complete unit is to be loosened and replaced.

12.1 Mechanical checking and remedies

Disconnect the mains power. Unlock all mechanical locks. Pull the door leaf manually and check that the door can be easily moved over the complete sliding track/floor guide. If the door leaf stops or is hard to move, the reason may be sand, stones, rubbish etc. in the floor guide. The door leaf may also be jamming on the floor or on the draught excluders. Clean the floor guide, adjust the door leaf height/depth or take other necessary measures e.g. replacement of wear parts until the door leaf is running smoothly when manually operated.

12.2 LED indication and CT Error codes

The control unit is equipped with a light emitting diode LED for error indication. By means of the configuration tool CT, a more detailed error description (CT error codes) can be obtained. See also separate manual for CT.


12.2.1 Normal operation/Non-critical errors








During normal operation and for non-critical errors the LED on the control unit is illuminated.

12.2.2 Power failure (no error code)

If the LED is extinguished check the mains power, power supply cable and perform a RESET. If the problem remains replace the control unit.

12.2.3 LED indication



- **Sensor error**
1 fast flash (0,2s), pause (1,0s) etc. 
- **Emergency Unit error**
2 fast flashes (0,4s), pause (1,0s) etc. 
- **CUF error**
3 fast flashes (0,6s), pause (1,0s) etc. 
- **Motor/Encoder error**
4 fast flashes (0,8s), pause (1,0s) etc. 
- **Lock error**
5 fast flashes (1,0s), pause (1,0s) etc. 
- **Motor Temperature High**
1 slow flash (1,8s), pause (0,2s) etc. 
- **Normal operation/Non-Critical errors**
Illuminated 

12.2.4 Sensor Error



LED indication: 1 fast flash (0,2s), pause (1,0s), etc.

CT error code	Reason	Remedy
Presence Impulse Error	The control unit doesn't get a test answer, from the activation unit.	Make sure that the monitoring output is connected and the connections are OK.
		Replace the presence activation unit.
Side Presence Impulse Error	The control unit doesn't get a test answer, from the activation unit.	Make sure that the monitoring output is connected and the connections are OK.
		Replace the side presence activation unit.
Inner Impulse Error	The control unit doesn't get a test answer, from the activation unit.	Replace the presence activation unit.
		Adjust sensor field so that the sensor can give a test answer.

12.2.5 Emergency Unit Error



The door is opened and stays open

LED indication: 2 fast flashes (0,4s), pause (1,0s), etc.

CT error code	Reason	Remedy
Emergency Action Timeout	The door is prevented from fulfilling its emergency unit test within a stated time, due to broken or weak rubber band, high friction or jammed door.	Check rubber band tension and make sure that the door can open to fully open position.
Emergency Unit Error	The battery voltage drops due to low capacity.	Charge or replace battery.
	The battery voltage measurement is wrong.	Replace the EXU-4 extension unit.
Battery Error	The battery is disconnected or short-circuited.	Make sure that the cables are OK and connected.
		Check the battery fuse.
		Charge or replace battery.

12.2.6 CUF error



LED indication: 3 fast flashes (0,6s), pause (1,0s), etc.

CT error code	Reason	Remedy
RAM Error	Internal RAM memory error.	RESET, and if the problem remains, replace the control unit.
ROM Error	Internal ROM memory error.	RESET, and if the problem remains, replace the control unit.
EEPROM Error	Serious internal EEPROM memory error.	RESET.
		Download a saved parameter set or DEFAULT parameter set and perform a RESET. If the problem remains, replace the control unit.
EEPROM Critical Write Error	Internal write EEPROM memory error. This error mainly occurs when it's impossible to change a configuration parameter.	RESET
		Try to change the configuration parameter that caused the problem, and if the problem remains, replace the control unit.
SMPS Over Voltage	The internal link voltage has for some reason increased to above 47 V.	RESET, and if the problem remains, replace the control unit.
A/D Converter Error	The internal A/D Converter or multiplexer is broken.	RESET, and if the problem remains, replace the control unit.
Lock Circuit Error	It is not possible to disconnect the lock with the lock relay.	RESET, and if the problem remains, replace the control unit.
Hardware Watchdog Error	It is not possible to disable the motor bridge.	RESET, and if the problem remains, replace the control unit.
Output Enable Error	Test of safety related circuits failing.	RESET, and if the problem remains, replace the control unit.
Register Error	Internal register error.	RESET, and if the problem remains, replace the control unit.
OS Error	Internal program error.	RESET, and if the problem remains, replace the control unit.
Flash Code Error	Serious internal programming error.	Replace the control unit.
Link Voltage Error	The internal link voltage measurement is wrong.	RESET, and if the problem remains, replace the control unit.

12.2.7 Motor / Encoder error



The motor and lock power are disconnected.

LED indication: 4 fast flashes (0,8s), pause (1,0s), etc.

CT error code	Reason	Remedy
Encoder Error	The encoder, encoder cable, or Motor cable is damaged.	Make sure that the encoder cable and the motor cable are connected.
	Wrong Motor type is selected.	Check Motor Type configuration with the CT-Tool.
Motor Current Error	The Motor cable or Encoder cable is damaged.	Make sure that the encoder cable and the motor cable are connected.
	Wrong Motor type is selected.	Check Motor Type configuration with the CT-Tool.
Encoder Cable Error	The encoder cable is damaged.	Make sure that the encoder cable is connected.

12.2.8 Lock error



The motor and lock power are disconnected.

LED indication: 5 fast flashes (1,0s), pause (1,0s), etc.

CT error code	Reason	Remedy
Lock Failure	The lock or something else was preventing the door from opening the first 14 mm from closed position.	Make sure that the lock is operating without friction.
		Make sure that Hold Force and Lock Release are set correctly.

12.2.9 Motor Temperature High



The door is opened and stays open.

LED indication: 1 slow flash (1,8s), pause (0,2s), etc.

CT error code	Reason	Remedy
Motor Temperature High	The duty cycle of the door is too high for the current speed settings and hold open time.	If the motor is warm, put the door in OPEN and wait for at least 1 minute. Reduce speeds and increase hold open time.
	The heavy-duty motor is replaced with a normal duty motor.	Put the door in OPEN and wait for at least 5 minutes.

Note! This error is not removable by RESET, only by setting the door in programme selection OPEN with the power on.

12.2.10 Non-Critical errors

These errors don't influence the door operation but are logged in the error log, and can only be displayed by means of the CT-Tool.

LED indication: Illuminated


CT error code	Reason	Remedy
Communication Error	The cable to the CT-Tool was removed before performing DISCONNECT from the CT-Tool.	Connect the CT-Tool and DISCONNECT from the CT-Tool before removing the cable.
EEPROM Access Error	The EEPROM queue is full.	Too many events to log in the event log. Reduce the number of events to log in the event log configuration.
EEPROM Non-critical Write Error	The control unit cannot write error log, event log, or service log information to the EEPROM memory.	RESET, and if the problem remains, replace the control unit if it is important to read log information.



12.3 After remedy or replacement the operator has to be checked as follows:

- a Study the door movement and adjust the functions to the values required for a smooth door operation.
- b Check that correct functions and values have been selected for the installed accessories and that the installation complies with valid regulations and requirements from the authorities.
- c Clean the cover and the doors.


13 Maintenance/Service





Regular inspections should be made according to national regulations and product documentation by a Besam-trained and qualified technician. The number of service occasions should be in accordance with national requirements and product documentation. This is especially important when the installation concerns a fire-approved door or a door with an emergency opening function. Refer to Besam Pro-Active Care option services to learn more about service possibilities!





ILL-02251





13.1 Maintenance plan

The table below shows the recommended interval - in months - when to replace parts during preventive maintenance.

Part	Part number	Cycles/hour in operation			Abusive Environment
		<10	<100	>100	
		Low traffic	Medium traffic	High traffic	
Electrical emergency unit battery	33550475	24	24	24	24
Mechanical emergency unit elastic cord	331700121	12	12	12	12
Floor guide shoe Felt padded	33831622	24	12	6	6
Carriage wheel Single Anti-derailing	830060 246313	36	24	12	12
Tooth belt	33735251	60	48	36	24

Check that all required signage, see page 33, is applied and intact. Also check other consumable parts, such as brushes, door stops and glazing rubbers.

14 Accessories

14.1 Safety accessories

Even though the CMD is installed to comply with all applicable safety regulations, it is possible to enhance safety/comfort with the following add-ons (please contact your local Besam company for detailed description).

- Combined motion and presence sensors
- Separate presence sensors

14.2 General accessories

Your CMD can be further improved with the following add-ons (please contact your local Besam company for detailed description).

- Cover

Made in clear anodized aluminium as standard. Paint finished in RAL colours or anodizing optional.

- Motion and presence sensors, see separate manuals or installation drawings.
- Programme selectors, and separate installation drawings 656037 and 656058.
- Electrical locks

Locked with power, locked without power or bistable lock.

See separate installation drawing 1002012.

- Micro switch kit

For indication of door and lock position.

- Electrical emergency unit with batteries

Used if a door is required to be opened or closed by means of a rechargeable battery unit and remain in this position in the event of power failure. Authorities can demand that the emergency unit is monitored on a regular time basis. Half an hour before this time has elapsed the following opening impulse generates an emergency opening test. If there is no opening impulse within an additional time, specified by the authorities, the operator control unit generates the opening impulse itself.

If the battery opens the door within the limited time the test is successful and the door resumes the function set by the programme selector.

Note! The test is never performed in programme selector setting OPEN. In setting OFF it can be selected. The test is always performed after a RESET and after changing program selection, from a position where a test is not done to a position where the test is a demand. See separate installation drawing 1005454.

- Mechanical emergency unit with elastic cord

Used if a door is required to be opened and remain opened by means of an elastic cord in the event of power failure. Authorities can demand that the emergency unit is monitored on a regular time basis. Half an hour before this time has elapsed the following opening impulse generates an emergency opening test. If there is no opening impulse within half an hour, the operator control unit generates the opening impulse itself.

If the elastic cord opens the door within the limited time the test is successful and the door resumes the function set by the programme selector.

Note! The test is never performed in programme selector setting OPEN. In setting OFF it can be selected. The test is always performed after a Reset and after changing program selection, from a position where a test is not done to a position where the test is a demand. See separate drawings 656008 and 1005454.

- Interlocking
Used between two operators when the first operator must close before the other one can open (typical to reduce energy losses and not for security reasons). EXU-4 required.
- Convenience battery UPS
Stand-by supply which gives continued operation during short power failure. EXU-3 or EXU-4 required. See separate installation drawing 656056.
- Emergency opening
Opens the door in any programme selector setting (fireman's opening). EXU-4 required.
- External error indication
Obtained if a lamp or a buzzer is connected. EXU-4 required.
- Key switches (flush and/or surface mounted)
Used to give opening impulse to the door in any programme selector setting. With electrical emergency unit also during power failure.
- Push button
Used to give opening impulse to the door.
See separate installation drawing 656005.

Australia:

Besam Australia Pty Ltd.,
235 Huntingdale Road,
Oakleigh Victoria,
Australia 3166
Tel: +61 1300 13 13 10
Fax: +61 3 8574 3865
admin@besamaustralia.com

Austria:

Besam Austria GmbH,
Hütteldorferstraße 216c,
1140 Wien
Tel: +43 1 914 55 37 0
Fax: +43 1 914 92 98
vertrieb@besam.at

Belgium:

Besam Belgium NV,
Centrum-Zuid 3042,
3530 Houthalen
Tel: +32 11 609 500
Fax: +32 11 604 680
info@besam.be

Canada:

Besam Canada, Inc.,
4090 Ridgeway Dr. Unit #16,
Mississauga, Ontario
L5L 5X5 Canada
Tel: 905 608 9242
Fax: 905 608 1151
general@besam.ca

China:

Besam Automatic Door Systems Trading
(Shanghai) Co. Ltd.,
Suite 1903,
Modern Communication
Commercial Tower
218, Hengfeng Road,
Shanghai, PRC 200070
Tel: +86 21 5128 8909
Fax: +86 21 5128 8919
info@besam.com.cn

Czech Republic:

Besam spol. s r.o.,
Košarova 23,
197 00 Praha - Kbely
Tel: +420 2 8600 1560
Fax: +420 286 001 570
besam@besam.cz

Denmark:

Besam A/S,
Marielundvej 20,
2730 Herlev
Tel: 44 53 70 80
Fax: 44 53 20 22
besam@besam.dk

Finland:

Besam OY,
Agronominraitit 2,
00790 Helsinki
Tel: +358 9 7288 5400
Fax: +358 9 799 292
besam@besam.fi

France:

Besam S.A.S.,
10 Rond Point du Général de Gaulle,
94864 Bonneuil s/Seine Cedex
Tel: +33 1 43 77 55 66
Fax: +33 1 43 39 56 00
besam@besam.fr

Germany:

Besam GmbH,
Lagerstraße 45,
64807 Dieburg
Tel: +49 6071 2080
Fax: +49 6071 208 111
info@besam.de

Hungary:

Besam Kft.,
Nagytétényi út 112,
1222 Budapest
Tel: +36 1 424 7274
Fax: +36 1 226 1949
besam@besam.hu

Italy:

Besam S.p.A.,
Via Monzoro 142,
20010 S
Pietro all'Olmo (MI)
Tel: +39 02 936 11 311
Fax: +39 02 936 21 16
besamsales@besam.it

Netherlands:

Besam Nederland BV,
Postbus 8155
6710 AD Ede
Tel: +31 318 69 89 69
Fax: +31 318 63 83 46
info@besam.nl

New Zealand:

Doorman Besam Ltd.,
10 Haultain St.,
PD Box 15 784 New Lynn,
Auckland 1232
Tel: +64 (0)9 815 8392
Fax: +64 (0)9 815 8391
admin@doormanbesam.co.nz

Northern Ireland:

Tel: +44 (0) 28 71 26 80 11
Fax: +44 (0) 28 71 27 11 15
info@besam.co.uk

Norway:

Besam Norge AS, Broekkveien 80
Postboks 25 Tveita,
0617 Oslo, Norway
Tel.: +47 69 24 53 00
Fax: +47 69 24 53 50
info@besam.no

Poland:

Besam Polska Sp. z o.o.,
ul. J. Olbrachta 94
PL-01-102 Warszawa
Tel: +48 22 331 86 80
Fax: +48 22 331 86 81
biuro@besam.com.pl

Portugal:

Besam Portugal,
Av. Marechal Gomes da Costa,
Fracção AD, 1º Piso, Cabo Ruivo
1800-255 Lisboa
Tel: +351 212 969 290
Fax: +351 212 974 132
apoiocliente@besam.com

Republic of Ireland:

Besam Ltd,
unit 39, Navan Enterprise Centre,
Trim Road
Navan, Co. Meath
Tel: +353 46 76747
Fax: +353 46 76745
info@besam.co.uk

Russia:

Besam Export AB (Russian office)
Box 120, Ovchinnikovskaya nab. 22/24, building 1
Moscow 115035 Russia
Tel: +7 495 542 97 25
Fax: +7 495 542 97 25
info@besam.ru

Singapore:

Besam (Mfg) Pte Ltd.,
No 33 Ubi Ave. 3 #03-52 Vertex
Singapore 408868
Tel: +65 6745 6228
Fax: +65 6745 7322
info@besam.com.sg

Slovak Republic:

Besam, spol. s r.o.,
Kapitulská 15,
811 01 Bratislava
Tel: +421 254 431 045
Fax: +421 254 431 247
besam@besam.sk

Spain:

Besam Ibérica S.A.,
Sepúlveda, 7A
28108 Alcobendas (Madrid)
Tel: +34 91 657 48 60
Fax: +34 91 661 43 80
informacion@besam.es

Sweden:

Besam Sverige AB,
Box 353
261 23 Landskrona, Sweden
Tel: +46 418 510 00
Fax: +46 418 140 60
swsales@besam.se
Besam Export AB
Box 669,
261 25 Landskrona
Tel: +46 418 514 00
Fax: +46 418 513 55
export@besam.se

United Kingdom:

Besam Ltd.,
Washington House,
Brooklands Close,
Sunbury on Thames,
Middlesex TW16 7EQ
Tel: +44 1932 765 888
Fax: +44 1932 765 864
info@besam.co.uk

US:

Besam US Inc.,
1900 Airport Road,
Monroe, NC 28110
Tel: +1 704 290 5520
Fax: +1 704 290 5555
marketing@besam-usa.com

**ASSA ABLOY**

ASSA ABLOY Entrance Systems AB, Box 131, SE-261 22 Landskrona, Sweden
Tel: +46 418 511 00 • Fax: +46 418 511 32
general@assaabloyes.com • www.besam.com