



**NOTES:**

1. FOR SIMULTANIOUS PAIR ENSURE THAT THE SYNC CABLE IS CONNECTED BETWEEN THE MASTER AND SLAVE
2. CAP OFF BLACK/ WHITE WIRE IF NOT USED.

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-249-7937 OR 1-866-836-1863/ MID-WEST: 1-800-407-4545 OR 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM

**BEA**  
OPEN UP NEW HORIZONS  
A HALMA GROUP COMPANY

100 ENTERPRISE DRIVE  
PITTSBURGH, PA 15275  
PHONE: (412) 249-4100  
FAX: (412) 249-4101  
EMAIL: www.beasensors.com

**TITLE: BESAM CU-2 W/ PARALLAX 2  
LO21B/U**

SIZE: <b>A</b>	DRAWN BY: WJR	REV BY: WJR	PART NO: <b>80.0296.01</b>
	SCALE: NONE	DATE: 12 AUG 09	SHEET 1 OF 1