



( See note 6 )

- NOTES: 1) DO NOT POWER ALL SENSORS FROM MASTER CONTROL BOX. POWER SOME OF THE SENSORS OFF OF THE SLAVE CONTROL.
- 2) ON BOTH CONTROLS SET PMD FUNCTIONS F20 = b, F19 = b, F18 = 00, F17=00, **F16 = 05**, F14 = a, F13 = a, F11 = 65 DEGREES. CAN BE SET TO 00
- 3) ON THE MASTER CONTROL SET FUNCTION F12 TO 3 DEGREES LESS THAN F10.
- 4) THE WIRING OF THE SUPERSCANS IS USING THE QUICK DISCONNECT CABLES WITH PREWIRED CONNECTOR ON SAFETY SIDE.
- 5) CONFIRM ALL SYNC LINES ARE PRESENT. ADDING SYNC LINES MAY BE REQUIRED.
- 6) DIPSWITCHES 1 THRU 5 LOCKOUT TIME. 6 (UP/OFF), 7 (UP/OFF), 8 (DOWN/ON).

IF AFTER TROUBLESHOOTING A PROBLEM, A SATISFACTORY SOLUTION CANNOT BE ACHIEVED, PLEASE CALL B.E.A., INC. FOR FURTHER ASSISTANCE DURING EASTERN STANDARD TIME AT 1-800-523-2462 FROM 8AM - 5PM. FOR AFTER-HOURS, CALL EAST COAST: 1-866-836-1863 OR 1-800-407-4545 / MID-WEST: 1-888-308-8843 / WEST COAST: 1-888-419-2564. DO NOT LEAVE ANY PROBLEM UNRESOLVED. IF YOU MUST WAIT FOR THE FOLLOWING WORKDAY TO CALL B.E.A., LEAVE THE DOOR INOPERABLE UNTIL SATISFACTORY REPAIRS CAN BE MADE. NEVER SACRIFICE THE SAFE OPERATION OF THE AUTOMATIC DOOR OR GATE FOR AN INCOMPLETE SOLUTION.WEB: WWW.BEASENSORS.COM

**BEA**  
 We open up New Horizons  
 HALMA GROUP COMPANY  
 100 ENTERPRISE DRIVE  
 PITTSBURGH, PA 15275  
 PHONE: (412) 249-4100  
 FAX: (412) 249-4101  
 EMAIL: www.beasensors.com

**TITLE: BESAM MP VER. 6.3,4 DUAL, LO21B/U  
 PASSPORT PLUS / PARALLAX 2,  
 Q-DISCONNECT ON SAFETY SIDE**

SIZE: <b>A</b>	DRAWN BY: KJG	REV BY: KJG	PART NO: <b>80.0043.07</b>
	SCALE: NONE	DATE: 4 JULY 2005	SHEET 1 OF 1