

PMD SETTINGS

FUNCTION	Master Value	Slave Value	Master W/ Parallax OHC	Slave W/ Parallax OHC	Navigator
	Factory OHC	Factory OHC			
01	65	all are	65	all are	65
02	10	the same	10	the same	20
03	20	exept: 8	20	exept: 8	10
04	30		30		25
05	10		10		10
06	20		20		10
07	00		00		05
08	02	00	02	00	04
09	00		00		04
10	90		90		70
11	10		65		10
12	60		87		60
13	A		A		A
14	A		A		A
15	00		00		01
16	04		04		04
17	20		00		20
18	00		00		00
19	B		B		B
20	A		B		A
21	00		00		00
22	35		35		10
23	00		00		00
24	A		A		A
25	00		00		02
26	A		A		A
27	A or B	RH or LH	A or B	RH or LH	A or B RH or LH

Fuction 15
00 = OHC
01= Navigator
02 = SM